

NectarCam : MC - Data Comparison

Thomas Tavernier

7 octobre 2019

thomas.tavernier@cea.fr


Overview

- 1 Flat field
- 2 single/multi photoelectron spectrum
- 3 NSB runs
- 4 Camera Layout

New pulse shape in the MC


old pulse shape

- from Flat field run at ~ 30 p.e.
- fadc_amplitude=14.0
- reconstructed pulse from MC is smaller and wider than from the data



new pulse shape


- from internal trigger run in the dark
- fadc_amplitude=16.2
- keeping events > 30 p.e.
- mostly muons and some afterpulses
- good agreement with the data !



New pulse shape in the MC


old pulse Amplitude / p.e.

- fadc_amplitude=14.0
- reconstructed Amplitude/p.e. : 12.5



new pulse Amplitude / p.e.


- fadc_amplitude=16.2
- reconstructed Amplitude/p.e. : 13.9



Charge resolution

- MC distribution of $\frac{Q_{\text{reco}}}{\langle Q_{\text{sim}} \rangle_{\text{mean}}}$
- Data distribution of $\frac{Q_{\text{reco}}}{\langle Q_{\text{reco}} \rangle_{\text{mean}}}$


$$Q_{\text{reco}} = \sum_{t_{\text{max}}-6}^{t_{\text{max}}+10} \text{smpl} - \text{pedestal}$$



MC Flat Field

photo_electron_image :


Broken or non illuminated pixels in the MC?



multi electron spectrum


mes spectrum

- Wider pedestals in the Data
 - electronic noise isn't Gaussian and uncorrelated
- Illumination is not the same



spe pdf


- good agreement
- dispersion is higher in the MC



Gain reconstruction


Gain estimation

- Wider distribution in the MC
- Very good agreement for the mean value



Gain estimation resolution


- precision of $\sim 5.7\%$
 - assuming I understand well the `dc_to_pe` parameter in the MC files.
 - only 10k events



NSB noise


Samples st.d. evolution with the NSB level :

- Non negligible mismatch between the MC and the data.
- Updated pulse shape & pulse amplitude did not solve the issue
- this is not understand yet




NSB noise


Samples distribution



max sample in wf





min sample in wf



NSB noise (integrated distribution)


Integrated pedestal st.d. evolution with the NSB level :

- Things goes better looking at the integrated distribution.



Camera Layout

One want to be sure we use the same layout for MC production and data analysis in ctapipe.




Summary


- Model have been updated :
 - New pulse shape.
 - New value for parameters `fadc_amplitude` & `fadc_lg_amplitude`
- The agreement is much better since the update.
- Disagreements remain with the samples distribution in the waveform with NSB
- Also :
 - Afterpulse spectrum cutoff in MC (max sample distribution)
 - 64 samples in the MC vs 60 in the data
 - Pixel with no charge in the MC ?

Bonus plots

pedestal sd.d. Vs number of integrated pixels (NSB ~ 500 MHz)



pedestal sd.d. Vs number of integrated pixels (NSB = 0 MHz)



NSB ~ 500 MHz

